



## CENTER DRAIN

### with EXTENSION PIECE

1. Determine the shower area drain center
2. Record the dimensions
3. Take the width dimension (23") and multiply by 2 ( $23 \times 2 = 46$ )
4. Take the depth dimension (17") and multiply by 2 ( $17 \times 2 = 34$ )
5. A 34 X 46 base (or larger) is needed to achieve your dimensions. Consult the EZ ShowerBase Sizes Chart.

**Order - EZ3648C and 30 X 12**

**EXTENSION PIECE**

See Installation Page for

Trimming Instructions

